

Advance 86a Personal Computer.

Preliminary manual.

(C) Advance Technology (UK) Ltd 1983.

ch kish : 131072 - 128 x 1024  
202704  

---

28,368

## Introduction.

Welcome to the Advance 86a personal computer.

This manual contains everything you need to know to unpack, setup your system and begin running programs. The Advance can display and process information in a wide variety of different forms - as text, text and graphics or a mixture of both. With its sixteen bit microprocessor, large memory, and powerful interfaces the Advance can handle many tasks that have been beyond the "home" or "low-cost" computers that have been available up until now. When you add the Advance system expansion unit the Advance becomes a disk based system that is hardware and software compatible with the IBM Personal computer - giving you instant access to the largest base of software available for any personal computer.

The Advance system unit is the centre piece of your system. Inside there is an 8086 microprocessor, RAM and ROM memory, and the necessary electronics to allow the Advance to communicate with you via a television or monitor display, a keyboard, and loudspeaker. Other connectors allow a cassette recorder, parallel printer, joysticks, light pen and expansion units to be plugged in.

Input to the system unit is through an 84 key keyboard which includes an alphanumeric section, separate numeric pad, and ten programmable function keys.

## System setup

Read carefully through the entire setup documentation BEFORE attempting to switch on your Advance computer. Treat the keyboard and system unit carefully - they are sophisticated pieces of electronics.

### NOTE:

Always remember. Before plugging or unplugging any cables, moving the system, or installing peripherals, make sure THE COMPUTER IS SWITCHED OFF AND DISCONNECTED FROM THE MAINS SUPPLY.

System setup consists of:

1. Unpacking.
2. Acquainting yourself with the various pieces of equipment that will be connected together.
3. Connecting the cables that link the various elements together.
4. Switching on for the first time.

Equipment needed:

1. The Advance 86a system unit.
2. The Advance 86 keyboard unit.

3. Mains power cord.
4. A domestic television or video monitor.
5. A video cable suitable for the type of display you are using.
6. An audio cassette recorder.
7. A cassette lead suitable for the cassette recorder.

If you are unsure about any of the above equipment your supplier will be able to help.

Clear a reasonable space on your work area. You will need easy access to both the front and rear of the Advance 86a system unit.

Position the system unit so that the plexiglass front is facing you.

Place the keyboard in front of the system unit. The plug on the coiled keyboard cable fits into the socket on the front of the system unit under the power switch. Make sure the plug is firmly seated - it should mate easily and there is no need to use any degree of force.

Check that the power switch is in the OFF (UP) position.

First connect the power cord to the socket at the back of the system unit and then to a mains outlet.

Position the power switch to ON. After a second or two you should hear one short beep from the loudspeaker, indicating that the system unit has completed its self-test.

If the power switch does not light, switch off, disconnect the power cord from the mains outlet, and check the power cord, fuse and plug.

If the loudspeaker gives a series of long or short beeps then the system unit is faulty. Contact your supplier.

SWITCH OFF AND DISCONNECT THE POWER CORD FROM THE MAINS OUTLET.  
YOUR COMPUTER, VIDEO DISPLAY, CASSETTE RECORDER SHOULD BE  
SWITCHED OFF AND DISCONNECTED FROM THE MAINS AT THIS TIME.

The next step is to connect your video display to the computer.

#### Connecting a television

Connect the video cable to the output of the UHF modulator at the back of the Advance system unit. Connect the other end of the video cable to the aerial input of your television.

Plug the system unit and television into the mains supply. As before after a second or two the computer should issue one short beep. Using the tuning control on your television you should be able to get a stable, legible display on the screen.

The display may be visible at several different positions of your TV's tuning control. You can use whichever setting produces the best display.

#### Connecting a video monitor

For a composite video monitor connect the video cable to the phono connector at the rear of the system unit. If you are using an RGB monitor plug the video cable into the DB9 connector at the rear of the system unit. Connect the other end of the video cable to the input connector on the video monitor. Plug the system unit and video monitor into the mains outlet and switch on. The computer should again issue a short beep, indicating that it is working correctly. On the video monitor you should see the Advance Basic sign on message.

If you are unable to get a satisfactory display on your television or monitor contact your supplier for assistance.

#### Connecting a cassette recorder

Connect your cassette lead to the DIN style connector at the rear of the system unit. Connect the other end of your cassette lead to the cassette recorder.

From Advance Basic the statements that control the cassette recorder are:

```
LOAD  
SAVE  
BLOAD  
BSAVE  
MOTOR
```

Cassette filenames should be enclosed in quotes.

With your Advance there should be a sample cassette with a program named colour on it. You can use this program to adjust your video display to get a high quality display.

To load colour, type

```
LOAD "COLOUR",R
```

The program will run immediately after it has loaded. If you get an error message whilst the system is loading adjust the volume and tone controls on your cassette recorder and try again.

## Advance Basic

Advance Basic may be used in either of two modes: direct mode or indirect mode. In direct mode, statements and commands are not preceded by line numbers. They are executed as they are entered. Results of arithmetic and logical operations may be displayed immediately and stored for later use, but the instructions themselves are lost after execution. Direct mode is useful for debugging and for using the Advance Basic interpreter as a calculator for quick computations that do not require a complete program.

Indirect mode is used for entering programs. Program lines are preceded by line numbers and stored in memory. At any time the program stored in memory can be executed by entering the RUN command.

## Line format

Advance Basic program lines have the following format:

<line number> <Basic statement>[:Basic statement...] <carriage return>

More than one Advance Basic statement may be placed on a line, but each must be separated from the last by a colon.

An Advance Basic program line always begins with a line number and ends with a carriage return. Line numbers indicate the order in which the program lines are stored in memory. Line numbers are also used as references in branching and editing. Line numbers must be in the range 0 to 65529. A line may contain a maximum of 255 characters.

A full stop character (.) may be used in EDIT, LIST, AUTO, and DELETE commands to refer to the current line.

## Active and visual display pages.

Every command that writes to or reads from the screen transfers information to the active screen. Advance Basic lets you switch between different active screens using the SCREEN statement. The screen which is actually being displayed is called the visual screen.

## Character set

The Advance character set consists of alphabetic characters, numeric characters, and special characters. In all a total of 256 different characters can be displayed. In the graphics modes you can redefine the character set at will.

## Constants

Constants are the values Advance Basic uses during execution. There are two types of constants: string and numeric.

A string constant is a sequence of up to 255 alphanumeric characters enclosed in double quotation marks.

For example:

```
"Hello world"  
"$25,000"  
"Hi there"
```

Numeric constants are positive or negative numbers. Advance Basic numeric constants cannot contain commas. There are five types of numeric constants:

1. Integer constants      Whole numbers between -32768 and 32767. Integer constants do not contain decimal points.
2. Fixed-point constants    Positive or negative real numbers.
3. Floating-point constants   Positive or negative numbers represented in exponential form.
4. Hex constants            Hexadecimal numbers, denoted by the prefix &H.  
For example:  
    &H76
5. Octal constants          Octal numbers, denoted by the prefix &O or &.  
For example:  
    &O377
6. Binary constants        Binary numbers denoted by the prefix &B.  
For example:  
    &B011

#### Single/double precision form for numeric constants

Numeric constants may be either single precision or double precision numbers. Single precision numeric constants are stored with 7 digits of precision, and printed with up to 6 digits. Double precision numeric constants are stored with 16 digits of precision and printed with up to 16 digits.

A single precision constant is any numeric constant that has one of the following characteristics:

1. Seven or fewer digits.
2. Exponential form using E.
3. A trailing exclamation point !

Examples:

```
46.8  
-1.09E-06  
3489.0  
22.5!
```

A double precision constant is any numeric constant that has one of these characteristics:

1. Eight or more digits
2. Exponential form using D.
3. A trailing number sign (#).

Examples:

```
345692811
-1.09432D-06
3489.0#
7654321.1234
```

### Variables

Variables are names used to represent values used in an Advance Basic program, the value of a variable may be assigned explicitly by the programmer, or it may be assigned as the result of calculations in the program. Before a variable is assigned a value, its value is assumed to be zero (or the null string "" for a string variable).

### Variable names and declaration characters

Advance Basic variable names may be of any length. Up to 40 characters are significant. Variable names can contain letters, numbers, and the decimal point. However, the first character must be a letter. Special type declaration characters (listed below) are also allowed.

A variable name may not be a reserved word, but embedded reserved words are allowed. Reserved words include all the Advance Basic commands, statements, function names, and operator names. If a variable begins with FN, it is assumed to be a call to a user defined function.

Variables may represent either a numeric value or a string. String variable names can be written with a dollar sign (\$) as the last character. For example A\$="sales report". The dollar sign is a variable type declaration character, that is, it "declares" that the variable will represent a string.

Numeric variable names may declare integer, single precision, or double precision values. The type declaration characters for these variable names are as follows:

**I** Integer variable

**S** Single precision variable

**D** Double precision variable

The default type for a numeric variable name is single precision.

Variable types may also be declared by including the Advance Basic statements DEFINT, DEFSTR, DEFSNG, and DEFDBL in a program.

#### Array variables

An array is a group or table of values referenced by the same variable name. Each element in an array is referenced by an array variable that is subscripted with an integer or an integer expression. An array variable name has as many subscripts as there are dimensions in the array. For example V(10) would reference a value in a one-dimensional array, T(1,4) would reference a value in a two-dimensional array, and so on. The maximum number of dimensions for an array is 255. The maximum number of elements per dimension is 32767.

#### Variable space requirements

Type	Bytes
Integer	2
Single precision	4
Double precision	8
Integer array	2 per element
Single precision	4 per element
Double precision	8 per element

Strings can be up to 255 characters in length.

#### Keyword entry

Advance Basic allows you to enter common Basic keywords quickly using the Alt key and a single alphabetic key (A-Z). The table below shows which keys are assigned keywords.

A - AUTO	N - NEXT
B - BSAVE	O - OPEN
C - COLOR	P - PRINT
D - DELETE	Q - Q
E - ELSE	R - RUN
F - FOR	S - SCREEN
G - GOTO	T - THEN
H - HEX\$	U - USING
I - INPUT	V - VAL
J - J	W - WIDTH
K - KEY	X - XOR
L - LOCATE	Y - Y
M - MOTOR	Z - Z



Advance cassette Basic commands, statements, functions.

ABS(x) - returns absolute value of X.  
ASC(x\$) - returns ASCII code of first letter of string X\$.  
ATN(x) - returns angle whose tangent is x in radians.  
AUTO [<line number> [, <increment>]] - generates line numbers automatically.  
BEEP - Sounds loudspeaker at 800Hz for 1/4 second.  
BLOAD filename[, offset] - loads a memory image from cassette into memory at offset.  
BSAVE filename, offset, length - saves a portion of memory to cassette.  
CALL <variable name> [( <argument list> )] - call assembly language subroutine.  
CDBL(x) - converts x to a double precision number.  
CHR\$(x) - Returns a string whose one character has the ASCII code x.  
CINT(x) - converts x to an integer.  
CLEAR [, <memspace>] [, <stack space>] - allocate memory, stack space. Clears variables, closes open files.  
CLOSE [(f) <file number> [, (f) <file number> ...]] - close open file(s).  
CLS - clears screen.  
COLOR [foreground] [, background] [, border] - sets colours in text mode.  
COLOR [background] [, palette] - sets colours in graphic modes.  
CONT - continues program execution after a break.  
COS(x) - returns cosine of x in radians.  
CSNG(x) - converts x to a single precision floating point number.  
CSRLIN - returns current line number of cursor.  
DATA <list of constants> - Stores numeric and string constants that are accessed by the READ statement.  
DEF FN<name> [( <parameter list> )] = <function definition> - define single line function.  
DEF SEG [=address] - define segment for subsequent BLOAD, BSAVE, CALL, PEEK, POKE USR statements.  
DEFINT <list of letters> - define variables whose names begin with specified letters as integers.  
DEFDBL <list of letters> - define variables whose names begin with specified letters as double precision variables.  
DEFSTR <list of letters> - define variables whose names begin with specified letters as string variables.  
DEFUSR [( <digit> )] [=integer expression] - define address of USR function.  
DELETE [( <line number> )] [- <line number>] - deletes program lines.  
DIM <list of subscripted variables> - declares array dimensions.  
EDIT <line number> - displays a line for subsequent editing.  
END - terminates program execution, closes all files, and returns to command level.  
EOF ((file number)) - Indicates an end-of-file condition.  
ERASE <list of array variables> - Deletes specified arrays.  
ERR - returns error code for last error encountered in program.  
ERL - returns line number of last error encountered in program.  
ERROR (x) - Simulates the occurrence of a BASIC error.  
EXP(x) - Exponential function. Returns e raised to the power x.  
FIX(x) - truncates x to an integer.  
FOR <variable name> = <start value> TO <end value> [STEP increment]  
NEXT [( <variable name> ) [, <variable name> ...]] - performs a series of BASIC statements in a loop a specific number of times.  
FRE(x) - returns amount of free storage in BASIC workspace.  
FRE(x\$) - returns amount of free storage in BASIC workspace. Forces string space garbage collection.

GOSUB <line number>  
 RETURN - transfers execution to and from subroutine at line number.  
 GOTO <line number> - transfers execution to line number.  
 HEX\$(x) - returns a string that represents the hexadecimal value of x.  
 IF ... THEN ..... ELSE - Conditional transfer of control.  
 IF ... GOTO ..... ELSE - Conditional transfer of control.  
 INKEY\$ - read character from keyboard.  
 INP(x) - read I/O port number x.  
 INPUT [;] ["prompt string";] <list of variables> - Returns input from keyboard during program execution.  
 INPUT # <file number>, <variable list> - input data from file.  
 INPUT\$ (len[, [f]filename]) - inputs string of specified length from file.  
 INSTR([I], x\$, y\$) - searches for string y\$ in x\$ beginning at position I.  
 INT(x) - returns integer value of x.  
 KEY key number, x\$ - sets function key to specified string.  
 KEY LIST - displays current function key assignments.  
 KEY ON - display function keys at bottom of screen.  
 KEY OFF - turn function key display off.  
 LEFT\$(x\$, I) - returns first I characters of string x\$.  
 LET <variable> = <expression> - assign expression value to variable.  
 LINE [(x1,y1) - (x2,y2) [, [colour] [, B[f]]] - draws lines or boxes.  
 LINE INPUT [;] ["prompt string";] stringvar - input line of text from keyboard  
 LINE INPUT #filename, stringvar - input line of text from file.  
 LIST [linenumber] [-linenumber] [, filename] - lists program text  
 LLIST [linenumber] [-linenumber] - lists program text on printer  
 LOAD [filename] [, R] - load program from cassette  
 LOCATE [row] [, [col] [, [cursor] [, [start] [, stop] ]]] - position, modify cursor  
 LOS(x) - returns the natural logarithm of x.  
 LPOS(x) - returns current position of printhead in buffer.  
 LPRINT <list of expressions> - prints values of expressions on printer.  
 LPRINT USING <string expression> ; <list of expressions> - prints formatted values of expressions on printer.  
 MERGE <filename> - Merges lines from ASCII program file with program in memory  
 MID\$(x\$, I[, I1])  
 MID\$(x\$, I[, I1]) = y\$ - extract or assign substring.  
 MOTOR <state> - switch cassette motor on or off.  
 NEW - deletes program in memory and clears all variables.  
 OCT\$(x) - returns string which is octal value of x.  
 ON ERROR GOTO <line number> - trap errors.  
 ON <expression> GOTO <list of line numbers> - Branches depending on value of expression.  
 ON <expression> GOSUB <list of line numbers> calls a particular subroutine depending on the value of the expression.  
 OPEN <mode>, [f] <file number>, <filename> [, <record length>]  
 OPEN <filespec> [FOR <mode>] AS [f] <file number> [LEN=<record length>] - Open data file.  
 OPTION BASE <0 or 1> - sets base value for array subscripts.  
 OUT <port number>, <x> - outputs x to specified port.  
 PEEK(x) - returns the byte pointed to by address x.  
 PEN ON - Enables light pen read.  
 PEN OFF - Disables reading of the light pen.  
 PEN(x) - Read light pen status.  
 POINT (x,y) - Returns colour of specified point on screen.  
 POKE x,y - Writes byte y into memory location x.

POS(x) - Returns current column of cursor.  
 PRESET [(xcoordinate), (ycoordinate)] [, (colour)] - draw point on screen.  
 PRINT <list of expressions> - print data on screen.  
 PRINT USING <string exp>; <list of expressions> - print formatted information.  
 PRINT# <filename> <list of expressions> - print information to file.  
 PRINT# <filename> USING <string> <list of expressions> - print formatted information to file.  
 PSET [(xcoordinate), (ycoordinate)] [, (colour)] - plot point  
 RANDOMIZE[<expression>] - seed random number generator.  
 READ <list of variables> - read values from data statement.  
 REM <text> - program comment.  
 RENUM [(new number) [, (old number) [, (increment)]]] - renumber lines.  
 RESTORE [(line number)] - Allows DATA to be reread from a specified line.  
 RESUME <line number> : <NEXT> : <O> - continue program execution after error.  
 RETURN - return from subroutine.  
 RIGHT\$(x\$, I) - return right I characters of string x\$.  
 RND(x) - return pseudo random number.  
 RUN [(line number)] - begin program execution.  
 SAVE filename [, A] or [, P]  
 SCREEN [mode] [, (burst) [, (page) [, (vpage)]]] - alter screen mode.  
 SGN(x) - returns the sign of x.  
 SIN(x) - returns sine of x, where x is an angle in radians.  
 SOUND frequency, duration - sound generation.  
 SPACE\$(x) - returns a string of x spaces.  
 SPC(x) - skips x spaces in a PRINT, LPRINT or PRINT# statement.  
 SQR(x) - returns the square root of x.  
 STICK(x) - return joystick coordinates.  
 STOP - terminates program execution, prints break message and returns to command level.  
 STR\$(x) - returns a string representation of the value of x  
 STRTAB - returns status of the joystick buttons.  
 STRING\$(n, #)  
 STRING\$(n, X\$) - returns a string of length x, all of whose characters have the ASCII code # (form 1), or all of whose characters are X\$ (form 2)  
 SWAP <variable name>, <variable name> - Exchanges the value of two variables.  
 TAB(x) - Move the print position to x.  
 TAN(x) - returns the tangent of x. X is the angle in radians.  
 TRON - enable tracing of program flow.  
 TROFF - disable tracing of program flow.  
 USR [(digit)] [(argument)] - call an assembly language routine.  
 VAL(x\$) - returns the numeric value of string x\$.  
 VARPTR (<variable name>)  
 VARPTR (&<file number>) - returns address of variable or file buffer.  
 WAIT <port number>, I[, J] - Loop until port has specific value.  
 WHILE <expression>  
 WEND - executes series of statements in loop as long as expression is true.  
 WIDTH [LPRINT] <size> 132  
 WIDTH <file number>, <size>  
 WIDTH <device>, <size> - alter line width.  
 WRITE - [(list of expressions)] - print data to the screen.  
 WRITE# <file number>, <list of expressions> - print data to a file.

### Extended key codes

The INKEY\$ statement will return a two character string when certain keys are pressed. If the first character returned by INKEY\$ is an ASCII NULL - 00, you should examine the second character to determine which key was pressed. Table shows the second character returned and the corresponding key.

Table

Code	Key
3	NULL
15	Back TAB (!<-)
16-25	Alt- Q,W,E,R,T,Y,U,I,O,P
30-38	Alt- A,S,D,F,G,H,J,K,L
44-50	Alt- Z,X,C,V,B,N,M
59-68	F1-F10
71	Home
72	Cursor Up ( )
73	PgUp
75	Cursor left ( )
77	Cursor right ( )
79	End
80	Cursor down ( )
81	PgDn
82	Ins
83	Del
84-93	Shift F1-F10
94-103	Ctrl F1-F10
104-113	Alt F1-F10
114	Ctrl PrtSc
115	Ctrl Cursor left
116	Ctrl Cursor right
117	Ctrl End
118	Ctrl PgDn
119	Ctrl Home
120-131	Alt 1,2,3,4,5,6,7,8,9,0,-,=
132	Ctrl PgUp

#### Advance Basic error messages.

Normally when Advance Basic detects an error the program is terminated and one of the error messages below displayed. It is possible to trap and test errors in a BASIC program using ON ERROR, ERR, and ERL.

Number	Message
1	Next without FOR ✓
2	Syntax error ✓
3	Return without GOSUB ✓
4	Out of data ✓
5	Illegal function call ✓
6	Overflow ✓
7	Out of memory ✓
8	Undefined line number ✓
9	Subscript out of range ✓
10	Duplicate definition ✓
11	Division by zero ✓
12	Illegal direct ✓
13	Type mismatch ✓
14	Out of string space ✓
15	String too long ✓
16	String formula too complex ✓
17	Can't continue ✓
18	Undefined user function ✓
19	No resume ✓
20	Resume without error ✓
21	Unprintable error ✓
22	Missing operand ✓
23	Line buffer overflow
24	Device timeout
25	Device fault
26	FOR without NEXT
27	Out of paper
28	Unprintable error
29	WHILE without WEND
30	WEND without WHILE
51	Internal error
52	Bad file number
54	Bad file mode
55	File already open
57	Device I/O error
62	Input past end
64	Bad file name
66	Direct statement in file
67	Too many files
68	Device unavailable

### Advance ROM BIOS.

The Advance 86 system has a ROM resident basic input/output system or BIOS. This provides device level control over the I/O devices on the system board. The BIOS routines give a programmer a standard, well defined interface to the system hardware. Most of the BIOS is concerned with communications - with the video screen, keyboard, printer, cassette, etc. In addition the BIOS provides various system services such as a real-time clock, equipment check, memory size determine etc. Table 1 summarises the functions available. Whilst the BIOS routines can be called from almost any language running on the Advance they are really intended for the use of experienced programmers who need a high degree of control over the system. Of necessity little error checking is performed by the BIOS routines and if you accidentally misuse them it is perfectly possible to "crash" the machine, losing all the work you have in memory.

#### Using the BIOS

The BIOS consists of a set of subroutines in ROM. Each subroutine can typically carry out several different functions. To chose which functions you load the appropriate parameters into the 8086 registers. To actually call the desired subroutine you issue a software interrupt.

For example, suppose we want to output a character to the parallel printer port. Parallel printer support is done via INT 17H. According to Table 2, INT 17H supports three different functions selected by loading register AH with 0,1 or 2. Function 0 outputs the character in AL to the parallel port. So, in assembly language the code to call the BIOS would look like:

```
MOV AH,0 ; Select function 0 - print a character
MOV AL,13 ; Print a carriage return code - ASCII 13
MOV DX,0 ; Select the first printer attached to the system
INT 17H ; Call printer support routine
; (Printer status is returned in AH)
```

As a rule the BIOS routines preserve all registers except AX and the flags. Note that some routines return status values in the other registers.

Table 1

Interrupt number	Function
10H	Video IO
11H	Equipment check
12H	Memory size determine
13H	Diskette IO
14H	RS 232 communications
15H	Audio cassette support
16H	Keyboard support
17H	Parallel printer
1AH	Real-time clock

Table 2

# VIDEO IO interrupt 10H

## AH=0 set mode

AL=0 40 x 25 BW Text  
 AL=1 40 x 25 Colour Text  
 AL=2 80 x 25 BW Text  
 AL=3 80 x 25 Colour Text  
 AL=4 320 x 200 Colour graphics  
 AL=5 320 x 200 BW graphics  
 AL=6 640 x 200 BW graphics

## AH=1 set cursor type

CL bits 0-4 End line for cursor  
 CH bits 0-4 Start line for cursor

## AH=2 set cursor position

DL column number  
 DH row number  
 BH page number - 0 for graphics

## AH=3 read cursor position

BH page number - 0 for graphics  
 returns  
 DL column  
 DH row  
 CL bits 0-4 end line for cursor  
 CH bits 0-4 start line for cursor

CURSOR-TYPE

0  
1  
2  
3  
4  
5  
6  
7

## AH=4 read light pen position

BH page number - 0 for graphics  
 returns  
 AH light pen switch status 0 = not down/triggered  
 1 = valid reading  
 DL column  
 DH row  
 CH raster line 0-199  
 BX pixel column 0-319 or 0-639

AH=5 change display page in text mode  
AL page number 0-7 in 40 col mode, 0-3 in 80 col mode

AH=6 scroll display page up  
AL number of lines, 0 means entire window  
CL column of upper left corner to scroll  
CH row of upper left corner to scroll  
DL column of lower right hand corner to scroll  
DH row of lower right hand corner to scroll  
BH screen attribute to use on blank lines

AH=7 scroll display page down  
AL number of lines, 0 means entire window  
CL column of upper left corner to scroll  
CH row of upper left corner to scroll  
DL column of lower right hand corner to scroll  
DH row of lower right hand corner to scroll  
BH screen attribute to use on blank lines

AH=8 return character/attribute at current cursor position  
BH screen page  
returns  
AL character at cursor position  
AH attributes of character at cursor position

AH=9 print character/attribute at current cursor position  
BH screen page  
CX number of characters to write  
AL ASCII code of character to write  
BL Attributes of character

A AH=10 print character at current cursor position  
BH screen page  
CX number of characters to write  
AL ASCII code of character to write

B AH=11 set colour palette  
BH colour palette  
BL colour value

C AH=12 write dot  
AL colour value - if bit 7=1 screen = screen XOR AL  
CX column number  
DX row number

D AH=13 read dot  
CX column number  
DX row number  
returns  
AL dot read

E AH=14 write character  
AL ASCII code of character to write  
BL Foreground colour in graphics mode  
BH Display page in alpha mode



F. AH=15 return current video state  
returns  
AL current screen mode  
AH number of character columns on screen  
BH current screen page

#### Equipment check INT 11H

returns  
AX = equipment attached to system

#### Memory size determine INT 12H

returns  
AX = number of 1K blocks of continuous memory

#### Cassette IO INT 15H

AH=0 Turn cassette motor on

AH=1 Turn cassette motor off

AH=2 Read 256 byte blocks from cassette

ES:BX pointer to data buffer  
CX number of bytes to read  
returns  
ES:BX pointer to last byte read + 1  
DX number of bytes actually read  
CY 0 if no error occurred, 1 if error in reading data  
AH Error code if CY=1  
01 - CRC error  
02 - data transitions were lost  
04 - no data was found

AH=3 write 256 byte blocks to cassette

ES:BX pointer to data buffer  
CX number of bytes to write  
returns  
ES:BX pointer to last byte written + 1  
CX 0

#### Keyboard INT 16H

AH=0 read next character from keyboard

returns  
AL character  
AH scan code

AH=1 Is character available ?

returns  
Z flag = 1 no code is available  
Z flag = 0 code is available  
if Z flag = 0 AX next character available in buffer

AH=2 Return current shift status  
returns  
AL = current shift status

#### Parallel printer INT 17H

AH=0 Print character  
AL character to be printed  
DX printer number 0,1 or 2  
returns  
AH =1 if timeout error

AH=1 Initialise printer port  
DX printer number  
returns  
AH printer status

AH=2 return printer status  
DX printer number  
returns  
AH printer status

#### Real-time clock INT 1AH

AH=0 Read current clock setting  
returns  
CX High portion of count  
DX Low portion of count  
AL 0 if timer has not passed 24 hours. Non 0 if another day

AH=1 Set current clock  
CX High portion of count  
DX Low portion of count

Advance 86 Connector specifications.

Keyboard connector J1.

Pin 1 Keyboard clock signal  
Pin 2 Keyboard data  
Pin 3 Not used  
Pin 4 0v  
Pin 5 +5v

Audio cassette connector J2.

Pin 1 Motor control output 1.  
Pin 2 0v.  
Pin 3 Motor control output 2.  
Pin 4 Data In.  
Pin 5 Data Out.

Loudspeaker J3.

Pin 1 Speaker drive.  
Pin 2 +5v.  
Pin 3 Not used

Joysticks J4.

Pins 1,8,9 & 15 +5v.  
Pins 4,5 & 12 0v.  
Pin 2 Push button input 1. Bit 4.  
Pin 7 Push button input 2. Bit 5.  
Pin 10 Push button input 3. Bit 6.  
Pin 14 Pushbutton input 4. Bit 7.  
Pin 3 Games paddle A, X axis input.  
Pin 6 Games paddle A, Y axis input.  
Pin 11 Games paddle B, X axis input.  
Pin 13 Games paddle B, Y axis input.

Centronics parallel printer J5.

Pins 2,3,4,5,6,7,8 & 9. These pins supply the 8 bit parallel data to the printer. The signals are TTL compatible. Data bit 0 is on pin 2 and data bit 7 on pin 9.  
Pins 18 & 25 0v.  
Pin 1 strobe (active low).  
Pin 10 acknowledge (active low).  
Pin 11 Busy (active high).  
Pin 12 Paper end.  
Pin 13 Printer select.  
Pin 14 Auto LF after CR (active low).  
Pin 15 Error.  
Pin 16 Initialise printer.  
Pin 17 Select In.

RGB Video out J6.

Pin 1 & 2 0v  
Pin 3 RED  
Pin 4 GREEN  
Pin 5 BLUE  
Pin 6 Intensity.  
Pin 7 Composite sync.  
Pin 8 Horizontal sync.  
Pin 9 Vertical sync.

These lines are all TTL compatible.

Composite video out J7.

This phono style connector supplies a composite video output to drive a composite video monitor - either monochrome or colour.

UHF Modulator

The UHF modulated output comes from the phono style connector on the UHF modulator. This is a PAL encoded composite video signal modulated onto an E36 carrier frequency. It is suitable for driving any domestic television - monochrome or colour.

## Advance 86a personal computer system specifications

Microprocessor 8086 running at 4.77 Mhz

ROM 64K bytes containing Microsoft 6W Basic interpreter  
Power on self test and diagnostic routines  
ROM BIOS

RAM 128K bytes as standard, with parity checking  
An additional 128K can be plugged into the system board

### Basic

Industry standard, compatible with IBM PC cassette BASIC  
Full screen editor built in  
Extensions for graphics, sound, light pen, joysticks all built in

Advance cassette 6W BASIC statements

ABS ASC ATN AUTO BEEP BLOAD BSAVE CALL CDBL CHR\$ CINT CLEAR  
CLOSE CLS COLOR CONT COS CSNG CSRLIN DATA DEF FN DEF SEG  
DEFTYPE DEF USR DELETE DIM EDIT END EOF ERASE ERR ERL ERROR  
EXP FIX FOR..NEXT FRE GOSUB..RETURN GOTO HEX\$ IF..THEN..ELSE  
INKEY\$ INP INPUT INPUT# INPUT\$ INSTR INT KEY LEFT\$ LEN LET  
LINE LINE INPUT LINE INPUT# LIST LLIST LOAD LOCATE LOG LPOS  
LPRINT LPRINT..USING MERGE MID\$ MOTOR NEW OCT\$ ON..ERROR  
ON..GOSUB ON..GOTO OPEN OPTION..BASE OUT PEEK PEN POINT  
POKE POS PRINT PRINT..USING PRINT# PRINT#..USING PSET PRESET  
RANDOMIZE READ REM RENUM RESTORE RESUME RETURN RIGHT\$ RND  
RUN SAVE SCREEN SGN SIN SOUND SPACE\$ SPC SQR STICK STOP STR\$  
STRIG STRING\$ SWAP TAB TAN TRON TROFF USR VAL VARPTR WAIT  
WHILE..WEND WIDTH WRITE WRITE#

### Video

Uses composite video/RGB/ or domestic television  
6845 CRT controller.  
Text modes Foreground/background colours programmable.

40 x 25

80 x 25

Foreground 1 of 16 colours

Background 1 of 8 colours

Border 1 of 16 colours

Bit mapped Graphics

160 x 100 16 colours

320 x 200 4 colours

Background 1 of 16 colours, 2 Palettes with 3 colours each

640 x 200 2 colours

256 characters including upper/lower case, scientific,  
European languages.

Text and graphics can be mixed freely on screen.  
In graphics modes character set can be redefined at will by the user

#### Keyboard

Separate detached unit 84 keys.

Keyboard layout, characteristics under software control and can be redefined at will.

Keys auto repeat when held down

10 Programmable function keys

Separate numeric/cursor control pad

Keyboard is interrupt driven so characters are never lost

#### Parallel printer

Industry standard Centronics parallel printer port

#### Audio cassette interface

Supports loading and saving of programs to audio cassette.

BASIC programs, data files, machine language programs and pure binary information such as graphics screens can all be loaded/saved.

#### Speaker

Loudspeaker programmable under software control

#### Joysticks/ Game paddle

Connections for two analogue joysticks. Four push button inputs

#### Light pen

Connector for Advance light pen

#### Co-processor

Provision for 8087 floating point co-processor chip on board.

#### Expansion

Can be connected to system expansion unit. Adds twin 360K disk drives, MSDOS, extended BASIC, Supercalc 3, Superwriter, RS232 interface, 4 IBM PC compatible bus slots, two true 16 bit slots.

This document describes the switch settings and video set up procedure for the Advance 86a system board

1. Switch Settings

1.1 Switch 1

This switch is used to define the type of display device connected to the system board. If a R.B.G. monitor is being used then the slider of SW1 should be in the position nearest the card edge. If a composite video or a domestic television is being used then the slider of SW1 should be set in the position nearest to I.C.66.

If the switch is set for R.G.B. monitor when using a domestic T.V. then unintensified characters will appear very faint on the display.

1.2 Switch 2

This is a four position D.I.L. switch located near I.C.93. Each of the four switch elements has the following effects.

1.2.1 Switch 2 element 1

This element is used to indicate if an Advance 86b expansion unit is fitted or not. For Advance 86a unit boards (unexpanded) this switch is set to the ON position.

If an expansion chassis is connected then this switch will be set to the OFF position.

1.2.2 Switch 2 element 2

This element is set to the ON position for use with PAL domestic T.V.s and PAL standard composite video monitors.

it is set to the OFF position for use with NTSC domestic T.V.s and NTSC standard composite video monitors.

For R.G.B. monitors the switch should be set to the OFF position.

1.2.3 Switch 2 elements 3 & 4

These two switches are not used. They will both be set to the OFF position on all boards.

1.3 Switch 3

This switch is positioned near I.C.109. It is used to determine the signal drive levels to the audio cassette.

The slider is set nearest to I.C.109 for audio cassette AUX. input. The slider is set nearest to J2 for audio cassette MIC. input.

2.0 Board Adjustments

2.1 Variable Resistor VR1

This potentiometer can be used to set the D.C. level of the video signal into the Astec modulator to achieve a video sync level (negative peak voltage) to 2.6 volts +/- 0.15 volts.

## 2.2 Variable Capacitor VC1

This variable capacitor adjusts the chrominance bandwidth of the video signal. VC1 is adjusted for maximum chrominance reference burst measured with an oscilloscope at the Astec modulator video input. The oscilloscope should be triggered on the line sync pulses.

## 2.3 Variable Capacitor VC2

This variable capacitor is used to adjust the frequency of the chrominance oscillator frequency to achieve a stable colour on a domestic T.V.

## Connector Pin Assignments

### 1.1 Connector J1

This is a 0.1 inch pitch male header used to connect to the keyboard.

Pin 1	Keyboard clock signal
Pin 2	Keyboard Data signal
Pin 3	Keyboard Reset (Not used)
Pin 4	0 Volts
Pin 5	+5 Volts

### 1.2 Connector J2

This is a 5 way 180 degree D.I.N. connector used to connect to the audio cassette.

Pin 1	Motor control output 1. Used with Pin 3 to control the cassette motor on recorders with a remote control facility.
Pin 2	0 Volts
Pin 3	Motor control output 2
Pin 4	Data In. This pin should be connected to the audio output of the cassette recorder.
Pin 5	Data Out. This pin should be connected to the AUX or MIC input of the cassette recorder. (See also notes on Switch 3)

### 1.3 Connector J3

This is a 0.1 inch pitch male header used to connect an 8 Ohm loudspeaker.

Pin 1	Speaker Drive Signal
Pin 2	+5 Volts (used as a return from the speaker)



#### 1.4 Connector J4

This is a 15 way D Type socket used to connect the games paddles.

Pins 1,8,9 & 15	+5 Volts
Pins 4,5 & 12	0 Volts
Pin 2	Pushbutton Input 1. When this pin is connected to 0 Volts then bit 4 of the games paddle register will be zero.
Pin 7	Pushbutton Input 2. When this pin is connected to 0 Volts then bit 5 of the games paddle register will be zero.
Pin 10	Pushbutton Input 3. When this pin is connected to 0 Volts then bit 6 of the games paddle register will be zero.
Pin 14	Pushbutton Input 4. When this pin is connected to 0 Volts then bit 7 of the games paddle register will be zero.
Pin 3	Games Paddle "A" , X axis input. (The other side of the games potentiometer should be connected to +5 Volts)
Pin 6	Games Paddle "A" , Y axis input.
Pin 11	Games Paddle "B" , X axis input.
Pin 13	Games Paddle "B" , Y axis input.

#### 1.5 Connector J5

This is a 25 Way D Type connector used to connect a parallel printer.

Pins 2,3,4,5,6,7,8 & 9	Data lines .(Data bit 0 is on pin 2) (Data bit 0 is on pin 9)
Pins 18 & 25	0 Volts
Pin 1	Strobe Signal (Active low)
Pin 10	Acknowledge (Active low)
Pin 11	Busy (Active high)
Pin 12	Paper End (Active high-no paper)
Pin 13	SCLT. (Active high)
Pin 14	Auto FD.XT (Active low)
Pin 15	Error (Active low-if error seen)
Pin 16	Initialise (Active low-normally high)
Pin 17	Select In (Active low)

#### 1.6 Connector J6

This is a 9 Way D Type socket used to connect a R.B.G. monitor.

Pins 1 & 2	0 Volts.
Pin 3	Red
Pin 4	Green
Pin 5	Blue
Pin 6	Intensity
Pin 7	Comp. sync. Contains vertical & horizontal sync information.
Pin 8	Horizontal sync
Pin 9	Vertical sync

All the above are T.T.L. compatible signals.

#### 1.7 Connector J6

This is a Phono Type socket supplying a composite video monitor output.

#### 1.8 Modulator U.H.F. or V.H.F. output

This is a phono style connector for used to connect a domestic T.V..

#### 1.9 Connector P1 & P2 (ISSUE 2 BOARDS)

These are 6 way 0.156 inch male headers, P1 is near I.C.5 & 6, P2 is near I.C.2 & 3, used to connect power.

P1	
Pins 1 to 5	+5 Volts
Pin 6	+12 Volts

P2	
Pins 2 to 6	0 Volts

#### 1.10 Connector P2 (ISSUE 3 BOARDS)

This is a 6 way 0.156 inch male header used to connect power.

Pin 2 & 3	0 Volts
Pin 4 & 5	+5 Volts
Pin 6	+12 Volts

#### 1.11 Connector P3

This is a 0.1 pitch male header used to connect a light pen.

Pin 1	LPen . Light Pen Signal input.
Pin 3	LPen Sw. Indicates if light pen is in contact with the screen.
Pin 4	0 Volts
Pin 5	+5 Volts
Pin 6	+12 Volts

## Advance Expansion Unit Connector

### Edge Connectors P1 & P2

P1

This is a 40 pin connector intended to connect pin for pin with edge connector P1 on the system board. (Pin 1 to Pin 1 - Pin 40 to Pin 40)

P2

This is a 34 pin connector intended to connect pin for pin with edge connector P2 on the system board.

### RS232 Serial Port

This is a 25 Way D Type Connector.

Pin 2	EIA TX DATA
Pin 3	EIA RX DATA
Pin 4	EIA RTS
Pin 5	EIA CLR TO SND
Pin 6	EIA DATA SET RDY
Pin 7	SIG GND
Pin 8	EIA CARRIER DET
Pin 9	+XM ITCL RET
Pin 11	-XM ITCL DATA
Pin 18	+RCV CL DATA
Pin 20	EIA DTR
Pin 22	EIA RI
Pin 25	-RCV CL RET

### Power Connector

Pin 1 & 2	+5 Volts
Pin 3	-5 Volts (Used on IBM cards but not by system)
Pin 4	-12 Volts
Pin 5	+12 Volts
Pin 6 & 7	0 Volts

### Floppy Disk Controller Board Connections

Edge connector J1 connects pin for pin with edge connector J1 on Disk Drive "A". (Pin 1 to Pin 1, Pin 34 to Pin 34 inc)  
Drive "A" connects to Drive "B" as follows

DRIVE "A"  
J1 Pins 1-9  
J1 Pins 10-16  
J1 Pins 17-34

DRIVE "B"  
J1 Pins 1-9  
J1 Pins 16-10  
J1 Pins 17-34

Note. A termination resistor pack (150 ohms) is required to be fitted in Drive "B" only.

### Procedure for setting up the Floppy Disc Controller Cards

Using an oscilloscope monitor the signal at TP2 and adjust VR2 to obtain a time interval of 2.0  $\mu$ secs from leading edge to leading edge. This represents a frequency of 500 KHz.

Monitor TP1 with the oscilloscope and using a DOS diskette in drive A attempt to boot the unit by pressing Ctrl, Alt and Del simultaneously or by switching OFF then ON.

Using VR1 set the pulse width of the positive signal at TP1 to 1  $\mu$ sec.

Note that the pulse width of the positive part of the signal at TP1 must not exceed the width of positive part of the signal at TP2.